



## ENDURO CAB CHASSIS.

MODEL	TYPE	W/BASE (mm)	GVM (kg)	GCM (kg)	ENGINE	TRANSMISSION
FA917 Enduro	4x2	4,250	9,000	11,500	4 Cyl. 3.9L, 125kW (170ps) / 520Nm	6 Sp. Manual
FA1017 Enduro	4x2	4,250	10,400	11,500	4 Cyl. 3.9L, 125kW (170ps) / 520Nm	6 Sp. Manual
FJ1628 Enduro	4x2	5,100	16,000	32,500	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual
FJ2528 Enduro	6x2	6,375	25,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual
FJ2528 Enduro	6x4	4,275	25,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual
FO3128 Enduro	8x4	5,175	31,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual

## ENDURO TIPPER.



MODEL	TYPE	W/BASE (mm)	GVM (kg)	GCM (kg)	ENGINE	TRANSMISSION
FI1217 Enduro Factory Tipper	4x2	3,760	12,000	13,500	4 Cyl. 3.9L, 125kW (170ps) / 520Nm	6 Sp. Manual
FJ2528 Enduro Factory Tipper	6x4	4,275	25,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual
FJ2528 Enduro CWS Tipper	6x4	4,275	25,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual



## ENDURO FLAT DECK.

MODEL	TYPE	W/BASE (mm)	GVM (kg)	GCM (kg)	ENGINE	TRANSMISSION
FA1017 Enduro Flat Deck	4x2	4,250	10,400	11,500	4 Cyl. 3.9L, 125kW (170ps) / 520Nm	6 Sp. Manual

## ENDURO CURTAINSIDER.



MODEL	TYPE	W/BASE (mm)	GVM (kg)	GCM (kg)	ENGINE	TRANSMISSION
FJ2528 Enduro Curtainsider	6x2	6,375	25,000	36,000	6 Cyl. 6.4L, Euro 5 210kW (285ps) / 1,120Nm	9 Sp. Manual